

SALTER®

SINCE 1760

MILKY LATTES
OR FOAMY
CAPPUCCINOS

Milk Frother

Enjoy creamy, frothy
drinks at home.



Please retain instructions for future reference.

Safety Instructions

When using electrical appliances, basic safety precautions should always be followed.

Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.

Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should be supervised to ensure that they do not play with the appliance.

Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.

This appliance is not a toy.

If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.

This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.

Keep the appliance and its power supply cord out of the reach of children.

Keep the appliance out of the reach of children when it is switched on or cooling down.

Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.

Keep the power supply cord away from any parts of the appliance that may become hot during use.

Keep the appliance away from other heat emitting appliances. Keep hands, fingers, hair and loose clothing away from the

rotating tools of the appliance.

Do not immerse the appliance in water or any other liquid.

Do not operate the appliance with wet hands.

Do not leave the appliance unattended whilst connected to the mains power supply.

Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.

Do not pull or carry the appliance by its power supply cord.

Do not use the appliance for anything other than its intended use.

Do not use any accessories other than those supplied.

Do not use this appliance outdoors.

Do not store the appliance in direct sunlight or in high humidity conditions.

Do not move the appliance whilst it is in use.

Do not touch any sections of the appliance that may become hot or the heating components of the appliance, as this could cause injury.

Do not use sharp or abrasive items with this appliance; use only heat-resistant plastic or wooden spatulas to avoid damaging the non-stick surface.

Always unplug the appliance after use and before any cleaning or user maintenance.

Always ensure that the appliance has cooled fully after use before performing any cleaning or maintenance or storing away.

Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.

Use of an extension cord with the appliance is not recommended.

This appliance should not be operated by means of an external timer or separate remote control system, other than that supplied with this appliance.

This appliance is intended for domestic use only. It should not be used for commercial purposes.

The outer surface or door may get hot during operation.



CAUTION: Hot surface – do not touch the hot section or heating components of the appliance.

WARNING: Boiling water and steam can cause serious injury; exercise extreme caution when using this appliance.

The appliance will become very hot during use; do not touch the appliance and always take care when handling.

Care and Maintenance

Switch off and unplug the Milk Frother from the mains power supply and allow it to cool fully before attempting any cleaning or maintenance.

STEP 1: Wipe the Milk Frother with a soft, damp cloth and dry thoroughly.

Do not immerse the Milk Frother in water or any other liquid.

STEP 2: Clean the interior of the Milk Frother with warm, soapy water, then rinse and dry thoroughly.

NOTE: The Milk Frother should be cleaned after each use.

WARNING: The Milk Frother is not safe for dishwasher use. Never immerse the electrical components in water or any other liquids.

Do not use harsh or abrasive cleaning detergents or scourers to clean the Milk Frother, as this could cause damage.

Description of Parts




- | | |
|---|--|
| 1. Milk Frother main body | 8. 300 ml max. fill mark
for heating function |
| 2. Milk Frother cup | 9. Indicator light |
| 3. Milk Frother base | 10. Lid |
| 4. Removable whisk | 11. On/off switch (ON/OFF) |
| 5. Whisk spindle | 12. Function button (FUNCTION) |
| 6. 75 ml min. fill mark | 13. Handle |
| 7. 150 ml max. fill mark
for frothing function | |

Instructions for Use

Before First Use

Clean the Milk Frother following the instructions in the sections entitled 'Care and Maintenance'.

Using the Milk Frother



Using the Milk Frother

The Milk Frother has four functions which can be used to create:

- Warm thick froth
- Warm thin froth
- Warm milk
- Frothed milk

Using the Milk Frother to Create Froth

STEP 1: Place the Milk Frother base onto a flat, stable, heat-resistant surface at a height that is comfortable for the user.

STEP 2: Position the removable whisk onto the spindle at the bottom of the Milk Frother cup.

STEP 3: Fill the Milk Frother cup with the desired amount of milk, between 75 and 150 ml.

STEP 4: Attach the Milk Frother lid then plug in and switch on the Milk Frother at the mains power supply.

STEP 5: Turn on the Milk Frother by pressing '**FUNCTION**' once for warm thick froth or twice for warm thin froth, followed by '**ON/OFF**'. The Milk Frother will begin operation. When the cycle is complete, the Milk Frother will turn off automatically.

STEP 6: Switch off and unplug the Milk Frother at the mains power supply. Using heatproof gloves, remove the Milk Frother lid and pour out the froth.

Using the Milk Frother to Warm Milk

STEP 1: Place the Milk Frother base onto a flat, stable, heat-resistant surface at a height that is comfortable for the user.

STEP 2: Position the removable whisk onto the whisk spindle at the bottom of the Milk Frother cup.

STEP 3: Fill the Milk Frother cup with the desired amount of milk, between 75 and 300 ml.

STEP 4: Attach the Milk Frother lid then plug in and switch on the Milk Frother at the mains power supply.

STEP 5: Turn on the Milk Frother by pressing '**FUNCTION**' three times, followed by '**ON/OFF**'. The Milk Frother will begin operation. When the cycle is complete, the Milk Frother will turn off automatically.

STEP 6: Switch off and unplug the Milk Frother at the mains power supply. Using heatproof gloves, remove the Milk Frother lid and pour out the milk.

Using the Milk Frother to Froth Milk

STEP 1: Place the Milk Frother base onto a flat, stable, heat-resistant surface at a height that is comfortable for the user.

STEP 2: Position the removable whisk onto the spindle at the bottom of the Milk Frother cup.

STEP 3: Fill the Milk Frother cup with the desired amount of milk, between 75 and 150 ml.

STEP 4: Attach the Milk Frother lid then plug in and switch on the Milk Frother at the mains power supply.

STEP 5: Turn on the Milk Frother by pressing '**FUNCTION**' four times, followed by '**ON/OFF**'. The Milk Frother will begin operation. For this function, the frothing paddle will rotate but the heating element will not heat up. When the cycle is complete, the Milk Frother will turn off automatically.

STEP 6: Switch off and unplug the Milk Frother at the mains power supply. Using heatproof gloves, remove the Milk Frother lid and pour out the milk.

Boil-dry Protection

If there is insufficient milk in the Milk Frother, it will automatically shut off. If this happens, switch off and unplug the Milk Frother from the mains power supply. Allow to cool fully for at least 10 minutes before using again.

Storage

Check that the Milk Frother is cool, clean and dry before storing in a cool, dry place. Never wrap the cord tightly around the Milk Frother; wrap it loosely to avoid causing damage.

Do not store the cord inside the Milk Frother.

Specifications

Product code: EK4635

Input: 220–240 V ~ 50–60 Hz

Output: 500 W

Connection To The Mains

Please check that the voltage indicated on the product corresponds with your supply voltage.

Important

As the colours in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, please proceed as follows:

The wires in the mains lead are coloured in accordance with the following code:

Blue Neutral (N)

Brown Live (L)

Green/Yellow Earth (\perp)

FOR UK USE ONLY - Plug fitting details (where applicable).

The wire coloured **BLUE** is the **NEUTRAL** and must be connected to the terminal marked **N** or coloured **BLACK**.

The wire coloured **BROWN** is the **LIVE** wire and must be connected to the terminal marked **L** or coloured **RED**.


The wire coloured **GREEN/YELLOW** must be connected to the terminal marked with the letter **E** or marked \perp .

On no account must either the **BROWN** or the **BLUE** wire be connected to the **EARTH** terminal (\perp).

Always ensure that the cord grip is fastened correctly.

The plug must be fitted with a fuse of the same rating already fitted and conforming to BS 1362 and be ASTA approved.

If in doubt, consult a qualified electrician who will be pleased to do this for you.



Non-Rewireable Mains Plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse need replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating).

If in doubt, consult a qualified electrician who will be pleased to do this for you.

If you need to remove the plug, **DISCONNECT IT FROM THE MAINS**, then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of an electric shock.

**UP Global Sourcing UK Ltd.,
UK. Manchester OL9 0DD.
Germany. 51149 Köln.**

If this product does not reach you in an acceptable condition please contact our Customer Services Department at www.salterhousewares.co.uk

Please have your delivery note to hand as details from it will be required.

If you wish to return this product, please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

Guarantee

All products purchased as new carry a manufacturer's guarantee; the time period of the guarantee will vary dependent upon the product. Where reasonable proof of purchase can be provided, Salter will provide a standard 12 month guarantee with the retailer from the date of purchase. This is only applicable when products have been used as instructed for their intended, domestic use. Any misuse or dismantling of products will invalidate any guarantee.

Under the guarantee, we undertake to repair or replace free of any charge any parts found to be defective. In the event that we cannot provide an exact replacement, a similar product will be offered or the cost refunded. Any damages from daily wear and tear are not covered by this guarantee, nor are consumables such as plugs, fuses etc.

Please note that the above terms and conditions may be updated from time to time and we therefore recommend that you check these each time you revisit the website.

Nothing in this guarantee or in the instructions relating to this product excludes, restricts or otherwise affects your statutory rights.

The crossed out wheelie bin symbol on this item indicates that this appliance needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authority for details of where to take the item for recycling.



*To be eligible for the extended guarantee, go to **guarantee.upgs.com/salter** and register your product within 30 days of purchase.

3
YEAR
GUARANTEE*

Find us on 

www.facebook.com/SalterUK

SALTER®

Manufactured by:

UP Global Sourcing UK Ltd.,
UK. Manchester OL9 0DD.
Germany. 51149 Köln.

Made in China.

©Salter trademark. All rights reserved.

