



User manual

Air fryer



Description of parts




Fig.1

- | | |
|----------------------------------|---------------------------------|
| 1. Top handle | 9. Mode buttons |
| 2. Air fryer main unit | 10. Temperature control buttons |
| 3. Cooking compartment | 11. LED display |
| 4. Compartment handle | 12. Temperature icon |
| 5. Digital control panel | 13. Time icon |
| 6. Non-stick coated cooking tray | 14. Time control buttons |
| 7. Fan icon | 15. Power button |
| 8. Heating icon | |

Please retain instructions for future reference.

SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities and knowledge, if they have been supervised/instructed and understand the hazards involved.
- Children shall not play with the appliance.
- Children should not perform cleaning or user maintenance, unless they are older than 8 and supervised.
- This appliance is not a toy.
- If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.
- This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
- Keep the appliance and its power supply cord out of the reach of children.
- Keep the appliance out of the reach of children when it is switched on or cooling down.
- Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.
- Keep the power supply cord away from any parts of the appliance that may become hot during use.
- Keep the appliance away from other heat emitting appliances.
- Do not allow the power supply cord to hang over worktops, touch hot surfaces or become twisted.
- Do not immerse the electrical components of the appliance in water or any other liquid.
- Do not operate the appliance with wet hands or if any connections are wet.
- If this appliance falls or accidentally becomes immersed in water, unplug it from the wall outlet immediately. Do not reach into the water.
- Do not leave the appliance unattended whilst connected to the mains power supply.
- Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
- Do not pull or carry the appliance by its power supply cord.
- Do not use the appliance for anything other than its intended use.
- Do not use any accessories other than those supplied.
- Do not use this appliance outdoors.

- Do not store the appliance in direct sunlight or in high humidity conditions.
- Do not move the appliance whilst it is in use.
- Always unplug the appliance after use and allow it to cool fully before any cleaning, user maintenance or storing away.
- Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.
- This appliance should not be operated by means of an external timer or separate remote control system.
- Use of an extension cord with the appliance is not recommended.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.



CAUTION: Hot surface – do not touch hot sections or heating components of the appliance.



WARNING: Keep the appliance away from flammable materials.

Automatic switch-off

The air fryer is fitted with an automatic switch-off. This may activate if the set cooking time has elapsed, causing the timer to sound and the automatic switch-off to activate, turning off the air fryer.



NOTE: If the air fryer needs to be turned off before the set cooking time has elapsed, switch off and unplug it from the mains power supply.

Dos and don'ts

DO:

Check that the non-stick coated cooking tray is securely fitted before use. Not doing so will prevent the air fryer from operating.

Only hold the cooking compartment by the handle.

Take care when removing the cooking compartment, as steam may be emitted.

Keep the air fryer upright when using the handle to move it.

Hold the air fryer from the base and keep it upright whilst carrying it using the handle.

DON'T:

Invert the cooking compartment with the non-stick coated cooking tray still attached, as it may fall out and excess oil that may have collected at the bottom of the cooking compartment may pour out onto the plate.


Cover the air fryer or its air inlets, as this will disrupt the airflow and could affect the cooking results.

Fill the cooking compartment with oil or any other liquid.

Touch the cooking compartment during or straight after use, as it gets very hot; only hold the cooking compartment by the handle.

Carry the air fryer when there is food in it.

Try to remove the handle or use it if it is cracked or broken.



WARNING: ENSURE THAT THE AIR FRYER HAS AT LEAST 20 CM OF FREE SPACE IN ALL DIRECTIONS BEFORE USE.

Care and maintenance

Before attempting any cleaning or maintenance, switch off and unplug the air fryer from the mains power supply and allow it to fully cool.

STEP 1: Wipe the air fryer main unit with a soft, damp cloth and dry thoroughly.

STEP 2: Clean the non-stick coated cooking tray in warm, soapy water, then rinse and dry thoroughly. Never use harsh or abrasive cleaning detergents or scourers to clean the air fryer or its accessories, as this could cause damage.



NOTE: The air fryer should be cleaned after each use.

Instructions for use

Before first use

Clean the air fryer following the instructions outlined in the section entitled '**Care and maintenance**'.

STEP 1: Before connecting the air fryer to the mains power supply, wipe the air fryer main unit with a soft, damp cloth and dry thoroughly.

STEP 2: Clean the non-stick coated cooking tray in warm, soapy water, then rinse and dry thoroughly.

STEP 3: Place the air fryer main unit onto a stable, heat-resistant surface, at a height that is comfortable for the user.



NOTE: When using the air fryer for the first time, a slight smoke or odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the air fryer during use. It is advised to run the air fryer without food for approx. 10 minutes before first use; this will prevent the initial smoke or odour from affecting the taste of the food.

Assembling the air fryer

STEP 1: Fit the non-stick coated cooking tray into the cooking compartment, checking that it is seated securely.

STEP 2: Slide the cooking compartment into the air fryer main unit to close it.



NOTE: The air fryer comes preassembled. The cooking compartment should be closed securely before use, as not doing so will prevent the air fryer from working.

Using the digital control panel

See 'Fig. 1'.

When the air fryer is plugged in and switched on at the mains power supply, the unit will beep and the power button will illuminate to indicate that it is connected to the mains power supply.

Tap the power button to switch on the air fryer.

The LED display will cycle between '200 °C' & '10 MINS'. These are the default cooking settings; if other settings are required, the time and temperature can now be programmed.

Press the temperature control buttons (↖ or ↘) to change the cooking temperature, up to a max. of 200 °C. The temperature icon will appear on the display when changing the temperature.

Press the time control buttons (↖ or ↘) to change the cooking time, up to a max. of 30 minutes. The time icon will appear on the display when changing the time.

Once time and temperature are set, tap the power button to begin heating.

The time and temperature can also be set using the 'MODE' buttons. This will automatically cycle between time and temperature presets for cooking various foods. These presets can then be adjusted using (↖ or ↘) to increase or decrease the time or temperature, as required.

Once the time has elapsed, the timer will sound and the air fryer will switch off. During cooking, the time and temperature can be adjusted at any time using (↖ and ↘).

To switch off the air fryer, tap the power button again.



NOTE: The power button will remain illuminated whilst the air fryer is plugged in.

Cooking chart

Icon	Function	Default temperature	Default time
	Chips	200 °C	15 mins
MANUAL	Manual	180 °C	15 mins
	Prawns	160 °C	20 mins
	Cake	160 °C	20 mins
	Drumstick	200 °C	25 mins
	Steak	180 °C	20 mins
	Fish	160 °C	20 mins
	Vegetable	190 °C	15 mins

Using the air fryer

STEP 1: Plug in and switch on the air fryer at the mains power supply; the air fryer will beep and the power button will illuminate to indicate that the unit is plugged in.

STEP 2: Tap the power button to switch on the air fryer; the LED display will show '200 °C', indicating that the time and temperature are ready to be programmed.

STEP 3: Following the instructions in the section entitled '**Using the digital control panel**', use the time and temperature control buttons to increase or decrease the time or temperature as required.

STEP 4: Remove the cooking compartment by pulling it out of the air fryer using the handle. Place the cooking compartment onto a flat, stable, heat-resistant surface.

STEP 5: Place the ingredients into the non-stick coated cooking tray and then slide the cooking compartment back into the air fryer main unit to close it.

STEP 6: Use the digital control panel to set the cooking time and temperature as required for the ingredients. Time and temperature can also be set using the mode buttons. This will automatically cycle between time and temperature presets for cooking various foods when pressed. These presets can then be adjusted using the time and temperature control buttons as required. Press the power button to begin cooking.

STEP 7: Some ingredients may require shaking halfway through the cooking time. Remove the cooking compartment from the air fryer main unit using the cooking compartment handle. Shake the cooking compartment gently and then slide it back into the air fryer main unit to continue cooking.

STEP 8: Once cooking is complete and the preset time has elapsed, the air fryer will beep several times and switch off. Check whether the ingredients are ready; if the ingredients are not cooked, close the cooking compartment and replace it back into the air fryer main unit. Use the digital control panel to adjust the cooking time accordingly. If the food is cooked, empty the contents into a bowl or onto a plate. Use a pair of heat-resistant tongs if the food is large or fragile.



NOTE: The air fryer will automatically adjust the settings. If the cooking compartment is removed during cooking, cooking will be paused; reinsert the cooking compartment to resume the cooking process.



CAUTION: Exercise caution when opening and closing the cooking compartment during use, as it will become very hot.

WARNING: Nominal voltage is still present even when the air fryer is switched off. To permanently switch off the air fryer, switch off and unplug from the mains power supply.

Storage

Check that the air fryer is cool, clean and dry before storing in a cool, dry place.

Never wrap the cord tightly around the air fryer; wrap it loosely to avoid causing damage.

Specifications

Product code: EK5735

Input: 220–240 V ~ 50/60 Hz

Output: 1300 W

UK
CA CE

Disposal of Waste Batteries and Electrical and Electronic Equipment



This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. Some retailers provide take-back services which allow the user to return exhausted equipment for appropriate disposal. **It is the user's responsibility to delete any data on electrical and electronic equipment prior to disposal.** For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

Manufactured by:
Ultimate Products UK Ltd.,
Victoria Street, Manchester OL9 0DD. **UK.**
Ultimate Products Europe Ltd.,
19 Baggot Street Lower, Dublin D02 X658. **ROI.**

MADE IN CHINA.

CD040523/MD030624/V1