

SALTER®

SINCE 1760

Deco Kettle

Practical, stylish design
for everyday use



Please read all of the instructions carefully and retain for future reference.

Safety Instructions

When using electrical appliances, basic safety precautions should always be followed.

Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.

Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should be supervised to ensure that they do not play with the appliance.

Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.

This appliance is not a toy.

This appliance contains no user serviceable parts. If the supply cord, plug or any part of the appliance is malfunctioning, or if it has been dropped or damaged, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.

Keep the appliance and its power supply cord out of the reach of children.

Keep the appliance out of the reach of children when it is switched on or cooling down.

Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.

Keep the power supply cord away from any parts of the appliance that may become hot during use.

Keep the appliance away from other heat emitting appliances.

Do not allow the power supply cord to hang over worktops, touch hot surfaces or become twisted.

Do not immerse the electrical components of this appliance in water or any other liquid.

Do not operate the appliance with wet hands, or if any connections are wet.

Do not expose the appliance to rain.

Do not leave the appliance unattended whilst connected to the mains power supply.

Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.

Do not pull or carry the appliance by its power supply cord.

Do not use the appliance if it has been dropped, if there are visible signs of damage or if it is leaking.

Do not use the appliance for anything other than its intended use.

Do not use any accessories other than those supplied.

Do not use any power supply base unit other than the one provided with this appliance.

Do not use this appliance outdoors.

Do not store the appliance in direct sunlight or in high humidity conditions.

Do not move the appliance when it is in use.

Do not fill the appliance above its max. fill mark.

Overfilling the appliance may cause boiling water to be ejected.

Do not touch any sections of the appliance that may become hot during use, as this may cause injury.

Always unplug the appliance after use and before any cleaning or user maintenance.

Always ensure that the appliance has cooled fully after use before performing any cleaning or maintenance or storing away.

Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.

Use of an extension cord with the appliance is not recommended.

This appliance should not be operated by means of an external timer or separate remote control system.

This appliance is intended for domestic use only. It should not be used for commercial purposes.

The heating element will remain hot after use.

Avoid overfilling as this may lead to spillage on the connector and thereby damage to the appliance.

Do not open the lid while the kettle is boiling.

Exercise caution when using this appliance, as steam will be emitted from the spout and/or lid, especially whilst refilling.



Caution: Hot surface – do not touch the hot section or heating components of the appliance.

Misuse of the appliance could potentially cause injury to the user.

Always allow the appliance to cool thoroughly before touching or opening the flip-top lid.

Warning: Boiling water and steam can cause serious injury; exercise extreme caution when using this appliance.

The appliance will become very hot during use; do not touch the appliance and always take care when handling.

Boil-dry Sensor

If the kettle is accidentally turned on whilst empty, the boil-dry sensor will activate causing the power to switch off. Do not try to use the kettle during this time; once it has cooled down, it will resume its normal function.

Care and Maintenance

Before attempting any cleaning or maintenance, unplug the kettle from the mains power supply and allow it to cool fully.

STEP 1: Wipe the kettle and base with a soft, damp cloth and allow to dry thoroughly.

STEP 2: If there is any solid residue on the inside of the kettle, carefully remove this with a damp cloth or brush.

Note: Never use harsh or abrasive cleaning detergents or scourers to clean the kettle and base, as this could cause damage.

Removing Limescale

If the kettle switches off before it has boiled or a white deposit is noticed on the inside of the kettle, it needs to be descaled. Add a commercial descaling agent to the kettle, adhering to the manufacturer's instructions. It is not recommended to use vinegar to descale the kettle.

Description of parts



- | | |
|---------------------------|---------------------------|
| 1. Deco Kettle | 6. Max. fill mark (1.7 L) |
| 2. Power base | 7. Water fill gauge |
| 3. Power switch | 8. Flip-top lid |
| 4. Handle | 9. Spout |
| 5. Min. fill mark (0.5 L) | 10. Lid release button |

Before First Use

Before using the kettle for the first time, wipe it clean with a soft, damp cloth and dry thoroughly.

Fill the kettle to the Max. fill mark and boil the water, following the instructions in the section entitled 'Using the 3000 W Deco Kettle'. After the water has boiled, pour it away. If any slight taste or odour remains in the boiled water, repeat this process.

Note: When using the kettle for the first time, a slight odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the kettle.

Warning: The kettle is not suitable for dishwasher use.

Instructions for Use

Using the 3000 W Deco Kettle

STEP 1: Position the power base onto a flat, stable, heat-resistant surface at a height that is comfortable for the user.

STEP 2: Press the lid release button to open the flip-top lid and fill the kettle to the desired water level. The water level must be between the min. fill mark and the max. fill mark on the water fill gauge.

STEP 3: Close the flip-top lid until it clicks securely shut and place the kettle back onto the power base.

STEP 4: Plug in and switch on the kettle at the mains power supply, then push the power switch to the 'on' position until it clicks. The power switch will automatically flip back into the 'off' position once the kettle has boiled.

STEP 5: Once the water has stopped boiling vigorously, lift the kettle by the handle and pour out the desired amount of water. Do not pour the water too quickly as this may cause it to trickle down the side of the kettle.

Caution: Allow the kettle to cool thoroughly before touching or opening the flip-top lid.

Do not use the kettle if the power base or any of the electrical connectors are wet. Do not attempt to dry these whilst the kettle is plugged in.

If the power switch will not stay clicked in the 'on' position, do not force it to stay down. This may cause excess steam to escape from the flip-top lid, damage to the automatic shut-off mechanism or injury to the user.

The body and flip-top lid of the kettle get very hot during use. Do not touch any part of the kettle except the handle whilst it is in use or filled with hot water.

To avoid spilling water or user injury, wait for vigorous boiling to subside before lifting the kettle or pouring water.

Warning: The flip-top lid may spray water if flipped open after boiling – allow the kettle to cool before opening the flip-top lid.

Storage

The kettle must be cool, clean and dry before storing in a cool, dry place. Never wrap the cord tightly around the kettle; wrap it loosely to avoid causing damage.

Specifications

Product code: EK2898

Input: 220–240 V ~ 50–60 Hz

Output: 2520–3000 W

Connection To The Mains

Please check that the voltage indicated on the product corresponds with your supply voltage.

Important

As the colours in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, please proceed as follows:

The wires in the mains lead are coloured in accordance with the following code:

Blue Neutral (N)

Brown Live (L)

Green/Yellow Earth (\perp)

FOR UK USE ONLY - Plug fitting details
(where applicable).

The wire coloured **BLUE** is the **NEUTRAL** and must be connected to the terminal marked **N** or coloured **BLACK**.

The wire coloured **BROWN** is the **LIVE** wire and must be connected to the terminal marked **L** or coloured **RED**.


The wire coloured **GREEN/YELLOW** must be connected to the terminal marked with the letter **E** or marked \perp .

On no account must either the **BROWN** or the **BLUE** wire be connected to the **EARTH** terminal (\perp).

Always ensure that the cord grip is fastened correctly.

The plug must be fitted with a fuse of the same rating already fitted and conforming to BS 1362 and be ASTA approved.

If in doubt, consult a qualified electrician who will be pleased to do this for you.



Non-Rewireable Mains Plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse need replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating).

If in doubt, consult a qualified electrician who will be pleased to do this for you.

If you need to remove the plug, **DISCONNECT IT FROM THE MAINS**, then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of an electric shock.

**UP Global Sourcing UK Ltd.,
Victoria Street, Manchester OL9 0DD. UK.**

If this product does not reach you in an acceptable condition please contact our Customer Services Department at www.saltercookshop.com.

Please have your delivery note to hand as details from it will be required.

If you wish to return this product, please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

Guarantee

All products purchased as new carry a manufacturer's guarantee; the time period of the guarantee will vary dependent upon the product. Where reasonable proof of purchase can be provided, Salter will provide a standard 12 month guarantee with the retailer from the date of purchase. This is only applicable when products have been used as instructed for their intended, domestic use. Any misuse or dismantling of products will invalidate any guarantee.

Under the guarantee, we undertake to repair or replace free of any charge any parts found to be defective. In the event that we cannot provide an exact replacement, a similar product will be offered or the cost refunded. Any damages from daily wear and tear are not covered by this guarantee, nor are consumables such as plugs, fuses etc.

Please note that the above terms and conditions may be updated from time to time and we therefore recommend that you check these each time you revisit the website.

Nothing in this guarantee or in the instructions relating to this product excludes, restricts or otherwise affects your statutory rights.

The crossed out wheellie bin symbol on this item indicates that this appliance needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authority for details of where to take the item for recycling.



*To be eligible for the extended guarantee, go to **www.saltercookshop.com** and register your product within 30 days of purchase.



Find us on 

www.facebook.com/SalterCookshop

SALTER[®]

Manufactured by:

UP Global Sourcing UK Ltd.,
Victoria Street,
Manchester OL9 0DD. UK.

Made in China.

