

# SALTER®

SINCE 1760

## TIMELESS COLLECTION 5 Piece Pan Set

Instruction Manual

### Before First Use

Hand-wash thoroughly.

### Using the Cookware



Suitable for use on gas, electric solid hot plates, halogen, radiant ring and induction hobs. Not suitable for use in a domestic or microwave oven, for deep fat frying, under a grill, on an open fire or barbecue. To avoid overheating the handles, do not place cookware on hob rings larger than the base size or allow flames to overlap the sides.

Use only heat-resistant plastic, silicone or wooden utensils; do not use metal ones.

Do not cut food in the cookware, as this will damage the surface.

Avoid leaving foods with a high salt content in the cookware, as this may cause pitting.

Do not overheat empty cookware.

Do not use the cookware over a high heat, as the non-stick coating is only suitable for use with medium heat settings.

Never leave cookware unattended whilst in use and ensure that the kitchen is well-ventilated.

Ceramic hobs can be scratched when moving cookware. To minimise damage, lift and place the cookware rather than drag it across the hob surface.

Any screws present on cookware may loosen over time. Using a screwdriver, retighten the screws as necessary. Be cautious with screws on glass lids, as overtightening may result in the lid being damaged.

### Cleaning the Cookware

Allow to cool thoroughly before moving or cleaning.

Do not pour cold water or liquid into hot cookware.

This cookware is safe for dishwasher use, however to best protect and preserve the cookware, hand-washing is recommended.

Clean the cookware in warm, soapy water with a mild detergent and a soft cloth; do not use harsh or abrasive cleaners or scourers; rinse and dry thoroughly.

If using a dishwasher, remove the cookware as soon as the cycle is complete and dry thoroughly. To remove stubborn stains, use a nonabrasive plastic mesh or pad with warm, soapy water. Do not leave the cookware to soak in water for long periods of time.

## Storage

Do not store wet cookware; store in a dry, clean place.

## Caution

Do not allow the handles to overlap adjacent hob rings or the edge of the hob.

The handles of the cookware may become hot during use; always use heat-resistant oven gloves to move it.

Do not allow the cookware to boil dry, as this can cause warping.

Never expose hot cookware to cold water or other liquid.

If the cookware becomes overheated, allow it to cool to room temperature before removing from the hob. Examine the condition and safety of the cookware before using again; if there is any evidence of damage dispose of it carefully.

Please retain this information for future reference.

If this product proves unsatisfactory or if you have any further queries, please contact your retailer.



Distributed by:  
UP Global Sourcing UK Ltd.,  
**UK.** Manchester OL9 0DD.  
**Germany.** 51149 Köln.

Made in China.

CD230321/MD000000/V1