

User manual

Knife Set



Please retain instructions for future reference.

SAFETY INSTRUCTIONS

- Knives are intended for domestic kitchen use only.
- Always use a plastic or wooden cutting board to avoid blunting the blades.
- Knives require regular sharpening and should be cleaned after each use.
- The knives should be checked for damage before each use. If there are any signs of damage, they should be disposed of carefully.



WARNING: SHARP
BLADES; HANDLE WITH
CARE. KEEP OUT OF THE
REACH OF CHILDREN.
NOT TO BE SOLD TO
ANY PERSONS UNDER
THE AGE OF 18.

Before first use

Hand-wash carefully and dry thoroughly.

Cleaning and maintenance

Not safe for dishwasher use.

Clean the knives in warm, soapy water with a soft cloth, rinse and dry thoroughly.

Do not soak.

Do not use harsh or abrasive cleaning detergents or scourers.

Wipe the knife block with a soft, damp cloth and dry thoroughly.

Storage

Store the knives carefully and safely within the knife block.

Manufactured by:
Ultimate Products UK Ltd.,
Victoria Street, Manchester OL9 0DD. **UK.**
Ultimate Products Europe Ltd.,
19 Baggot Street Lower, Dublin D02 X658. **ROI.**
MADE IN CHINA.

CD270624/MD000000/V1