




# User manual

Health grill

---



## Description of parts



- |                                    |                             |
|------------------------------------|-----------------------------|
| 1. Health grill main unit          | 8. Temperature control dial |
| 2. Upper housing                   | 9. Drip tray                |
| 3. Lower housing                   | 10. 180° locking button     |
| 4. Non-stick coated cooking plates | 11. Lock and lift lever     |
| 5. Handle                          | 12. Angle adjustment feet   |
| 6. Red power indicator light       | 13. Non-slip feet           |
| 7. Green ready indicator light     |                             |

Please retain instructions for future reference.

## **SAFETY INSTRUCTIONS**

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure that they do not play with the appliance.
- Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.
- This appliance is not a toy.
- If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.
- This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
- Keep the appliance and its power supply cord out of the reach of children.
- Keep the appliance out of the reach of children when it is switched on or cooling down.
- Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.
- Keep the power supply cord away from any parts of the appliance that may become hot during use.
- Keep the appliance away from other heat emitting appliances.
- Do not allow the power supply cord to hang over worktops, touch hot surfaces or become twisted.
- Do not immerse the electrical components of the appliance in water or any other liquid.
- Do not operate the appliance with wet hands.
- Do not leave the appliance unattended whilst connected to the mains power supply.

- Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
- Do not pull or carry the appliance by its power supply cord.
- Do not use the appliance for anything other than its intended use.
- Do not use any accessories other than those supplied.
- Do not use this appliance outdoors.
- Do not store the appliance in direct sunlight or in high humidity conditions.
- Do not move the appliance whilst it is in use.
- Do not touch any sections of the appliance that may become hot during use, as this may cause injury.
- Do not use the appliance near or below flammable materials, such as curtains, wall cupboards or shelves.
- Do not use sharp or abrasive items with this appliance; use only heat-resistant plastic or wooden spatulas to avoid damaging the non-stick surface.
- Always unplug the appliance after use and ensure it has cooled fully before performing any cleaning, user maintenance or storing away.
- Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.
- Use of an extension cord with the appliance is not recommended.
- This appliance should not be operated by means of an external timer or separate remote control system, other than that supplied with this appliance.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.
- The outer surface of the appliance may get hot during operation.



**CAUTION:** Hot surface – do not touch the hot section or heating components of the appliance. Take care not to pour water on the heating element.



**WARNING:** Keep the appliance away from flammable materials.

## Care and maintenance

Before attempting any cleaning or maintenance, unplug the health grill from the mains power supply and allow to cool fully.

**STEP 1:** Use the angle adjustment feet to channel any excess oil into the drip tray.

**STEP 2:** Wipe the health grill housing with a soft, damp cloth and dry thoroughly.

**STEP 3:** Remove baked on food by applying a small amount of warm water mixed with a mild detergent to the non-stick plates, then wipe them clean with a paper towel. Use a nonabrasive scourer if the food is difficult to remove.

Never use harsh or abrasive cleaning detergents or scourers to clean the health grill or its accessories, as this could damage the surface.



**NOTE:** The health grill should be cleaned after each use.



**WARNING:** The drip tray will gather oil and fat, which may still be hot after use. Allow it to cool fully before carefully removing the drip tray for cleaning.

## Instructions for use

### Before first use

**STEP 1:** Check that the health grill is switched off and unplugged from the mains power supply.

**STEP 2:** Wipe the health grill housing with a soft, damp cloth and dry thoroughly.

**STEP 3:** Clean the accessories in warm, soapy water, then rinse and dry thoroughly.



**NOTE:** When using the health grill for the first time, a slight smoke or odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the health grill.

## Using the health grill

**STEP 1:** Position the drip tray underneath the end of the oil channel.

**STEP 2:** Prepare the ingredients that are to be grilled.

**STEP 3:** Plug in and switch on the health grill at the mains power supply, making sure that the temperature control dial is set to the 'off' position. The red power indicator light will illuminate, signalling that the health grill has been switched on.

**STEP 4:** Select the required temperature; the green ready indicator light will turn on, signalling that the health grill is heating up.

**STEP 5:** Preheat the health grill for approx. 2–5 minutes. The green ready indicator light will switch off once the required temperature has been reached.

**STEP 6:** Place the prepared ingredients onto the lower cooking plate and then close the lid. Depending on the size of panini or other cooking ingredients the lock and lift lever can be used to raise the grill to better fit the ingredients.

**STEP 7:** If using the health grill as a griddle plate, push the 180° locking button in and open the health grill so that it lies flat. Place the prepared ingredients onto the cooking plates. If only one cooking plate is needed, make sure that the lower non-stick plate is used for optimum cooking performance.

**STEP 8:** Cook for approx. 3–8 minutes, depending upon the type of ingredients and the temperature used.

**STEP 9:** Once cooking is complete, carefully open the lid (if required) and remove the food with a heat-resistant plastic or wooden spatula.

**STEP 10:** Turn the temperature control dial to the ‘off’ position, then switch off and unplug the health grill from the mains power supply.

**STEP 11:** Leave the lid open and allow to cool.

**STEP 12:** Use the angle adjustment feet to channel any excess oil into the drip tray.



**NOTE:** Always preheat the non-stick plates before starting to cook. During use, the green ready indicator will cycle on and off to signal that the health grill is maintaining temperature. To prolong the life of the non-stick coating, carefully apply a thin coat of cooking oil to the non-stick cooking plates, rubbing it in gently with a paper towel. Using the health grill as a griddle plate will increase the amount of runoff; empty the drip tray regularly to prevent it from overflowing.



**CAUTION:** The non-stick plates get very hot during use; always use heat-resistant gloves to avoid injury. The angle adjustment feet will channel any excess oil into the drip tray. This can get very hot; always use heat-resistant gloves to avoid injury. Take care when placing food onto the non-stick plates, as fatty, oily or wet ingredients may create splashback, which could cause injury.



**WARNING:** Exercise caution during cooking; the health grill will emit steam.

## **Storage**

Check that the health grill is cool, clean and dry before storing in a cool, dry place. Never wrap the cord tightly around the health grill; wrap it loosely to avoid causing damage.

## **Specifications**

Product code: EK5857

Input: 220–240 V ~ 50–60 Hz

Output: 2000 W



# RECIPES

## Rosemary shrimp skewers with rocket and white bean salad

Skewers are required for this recipe.

### Ingredients

680 g large shrimps, shelled and cleaned with tails on skewers

### For the marinade

3 garlic cloves, crushed

3 tbsp extra virgin olive oil

3 tbsp lemon juice

2 tsp fresh rosemary, finely chopped

Salt and pepper, to taste

### For the salad

425 g cannellini beans, rinsed and drained

142 g baby rocket

1 garlic clove, minced

½ small red onion, thinly sliced

2 tsp lemon juice

1 tsp extra virgin olive oil

Pinch of sugar

Salt and pepper, to taste

### Method

Combine the olive oil, lemon juice, crushed garlic cloves and rosemary in a large bowl or sealable container; season to taste with the salt and pepper. Add the shrimps to the mixture and coat thoroughly in the marinade. Seal the bowl with shrink wrap or the lid of the container and refrigerate for approx. 15 minutes. Preheat the health grill once the shrimps are marinated.



Thread the shrimps onto the skewers. Place the loaded skewers onto the lower non-stick plate, close the lid and cook for approx. 3 minutes, until the shrimps are pink.

Whilst the shrimps are cooking, create the salad by mixing the minced garlic, sugar, olive oil, lemon juice, salt and pepper in a large bowl. Add the rocket, cannellini beans, and onion; toss to combine.

Serve the salad on one side of a large platter and arrange the shrimp skewers alongside to serve.

## **Grilled chicken with mozzarella cheese**

### **Ingredients**

4 boneless chicken breasts  
8 slices mozzarella cheese  
4 tomatoes, sliced  
3 tbsp olive oil  
2 tsp fresh rosemary, chopped  
½ tsp garlic powder  
¼ tsp salt  
¼ tsp black pepper  
Basil to garnish

### **Method**

Open the health grill so that it lies flat and then preheat.

Slit each of the chicken breasts horizontally to make a pocket and then fill with the sliced tomato and mozzarella cheese.

Brush the chicken breasts with olive oil and season with salt, pepper, rosemary and garlic powder.

Place the chicken breasts onto the lightly oiled non-stick plates and cook for approx. 9 minutes per side or until the juices run clear and the chicken is cooked thoroughly.

Remove from the health grill and arrange on serving plates.

Garnish with basil.

## **Chicken quesadillas**

### **Ingredients**

2 flour tortillas  
80 g cooked chicken, shredded  
(or turkey, if preferred)  
10 g butter, melted  
4 spring onions, finely chopped  
1 small finely chopped red chilli pepper  
2 tbsp grated cheddar cheese  
1 tbsp pitted black olives, finely chopped  
Salt and pepper

### **Method**

Coat one side of each tortilla with a little melted butter.

Preheat the health grill.

Place all of the other ingredients, except the tortillas and 5 g butter, into a bowl and mix well.

Season with salt and pepper, to taste and divide the mixture equally between the 2 tortillas.

Fold each tortilla in half and lightly brush with the remaining butter.

Place the tortillas onto the lower non-stick plate, close the lid and cook for approx. 6 minutes or until the chicken is hot, the cheese has melted and the tortillas are lightly golden brown and crispy.

Serve warm with salsa or salad.

## **Home-made beef burgers**

### **Ingredients**

350 g freshly ground beef  
1 egg  
1 tsp dried mixed herbs  
(thyme and oregano)  
Salt and freshly ground black pepper

### **Method**

Preheat the health grill.

Mix the beef and herbs together in a mixing bowl, add the egg and season well.

Divide into 2 portions and shape into burgers.

Place the burgers onto the lower non-stick plate, close the lid and cook for approx. 7–9 minutes or until thoroughly cooked and browned. Serve in burger buns with relish and salad.





#### Disposal of Waste Batteries and Electrical and Electronic Equipment



This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. Some retailers provide take-back services which allow the user to return exhausted equipment for appropriate disposal. **It is the user's responsibility to delete any data on electrical and electronic equipment prior to disposal.** For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

Manufactured by:  
Ultimate Products UK Ltd.,  
Victoria Street, Manchester OL9 0DD. **UK.**  
Ultimate Products Europe Ltd.,  
19 Baggot Street Lower, Dublin D02 X658. **ROI.**

**MADE IN CHINA.**

CD040923/MD290124/V3