

# SALTER




## LEAVE-IN DIGITAL THERMOMETER

### Instructions and Guarantee




Register your product today at  
[www.salterhousewares.co.uk/product-registration](http://www.salterhousewares.co.uk/product-registration)

### Quick start guide





### Oven use reminder





Remember to keep the cord end of the probe clear of the oven walls and heating element

PLEASE READ THIS INSTRUCTION MANUAL BEFORE USE. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

### USING YOUR THERMOMETER

1. Press the  button on the left side of the product to switch on.
2. Press and hold the  button on the left side of the product to switch off.
3. Plug the probe jack into the port at the top of the product. The probe will click into place when connected.
4. Ensure the probe is correctly connected and reading the ambient temperature.
5. To Take an Instant Reading:
  - Insert the metal probe tip into the centre (thickest part) of the food.
  - Leave the probe in the piece of food until the temperature settles.

### TO SELECT A COOKING MODE/ TO USE:

1. Ensure the product is not already set to a specific cooking mode. If so, reset the device.
2. Use the top < or > buttons to select your food type.
3. Confirm your selection with the  button on the right side of the product.
4. Beef/lamb will require you to select the temperature according to the level of "doneness" you require (I.E rare – well done).
5. Your selections will scroll across the screen below the main temperature reading.
6. For meat, fish and poultry insert the tip of the probe into the centre (thickest part) of the food.  
Ensure probe is not in contact with bone, fat or gristle as this will affect the validity of the reading.
7. Unwind the cable and carefully place food with probe inside the preheated oven. Run the cord through the oven door, by carefully closing it onto the cord and position the timer display unit near the oven. The display unit **MUST NOT** be placed in the oven.
8. When the internal temperature of the food reaches the target temperature, the alarm will start to sound. The alarm will continue to sound for 1 minute or until switched off using the  button.

### TO RESET THE THERMOMETER:

1. Press and hold the two top (< & >) buttons.

### CHANGING BETWEEN °C (Celsius) /°F (Fahrenheit)

1. Remove battery door.
2. Move switch to preferred setting.
3. Re-insert battery door.

### RESTING MEATS:

Once meat/poultry has reached its final temperature, always rest for a minimum of 3 minutes before carving/serving.

### CHANGING BATTERY:

1. Remove battery door.
2. Insert new batteries (2x AAA), ensuring +/- terminals are the correct way around.
3. Replace battery door.

### PRODUCT WARNING INDICATORS:



### CLEANING:

1. Remove the probe from the thermometer.
2. Always clean the probe thoroughly after each use. Wipe clean with a damp cloth. **DO NOT** use chemical or abrasive cleaning agents. **DO NOT** place in dishwasher.
3. We recommend that the thermometer probe is sterilised before each use e.g. insert the probe stem only in boiling water for a few minutes.
4. After washing the probes, ensure the cable connector is completely dry before connecting to the main display unit.
5. All plastic parts should be cleaned immediately after contact with fats, spices, strongly flavoured/coloured food.


**CARE AND PRECAUTIONS:**

- Always remove flat batteries immediately.
- We recommend changing the batteries after 1 to 2 years, to prevent the batteries corroding in the product.
- Always wear heat resistant gloves when handling the thermometer probe and cord.


**WARNING HOT SURFACE!**

- **DO NOT** immerse the thermometer body in liquid or splash any water onto this section. The internal components could become damaged if they come into contact with water.
- The thermometer is **NOT** suitable for use in a microwave.  
**DO NOT** place thermometer display unit inside oven or grill. Only the probes and cords are designed for use inside the oven.
- Probe and cord cannot exceed temperatures of 250C/480F.

**WEEE EXPLANATION**

 This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

**BATTERY DIRECTIVE**

 This symbol indicates that batteries must not be disposed of in the domestic waste as they contain substances which can be damaging to the environment and health. Please dispose of batteries in designated collection points.

**ELECTROMAGNETIC COMPATIBILITY** This product is intended for domestic use.

**ADVICE TO THE USER** This product is a sensitive electronic instrument and as such may temporarily be affected by Radio Transmitting Devices being used in close proximity to it (such as Mobile Phones, Walkie Talkies, CB Radios, Radio Model Controllers, and some Microwave Ovens, etc.) Additionally, extreme levels of Electrostatic Interference may cause this product to temporarily malfunction. In such case it may be necessary to remove and re-install the battery to re-establish normal working. If the problem persists then contact your local agent.

**TEMPERATURE CHARTS**

Below are charts showing the pre-programmed temperatures used by the thermometer. The manufacturer accepts no responsibility or liability for food borne illnesses which may occur from food prepared using the product or temperature charts.

		(°C)	(°F)
<b>Beef</b>	Rare	50	122
	Medium Rare	55	131
	Medium	60	140
	Medium Well	65	149
	Well Done	70	158
<b>Poultry</b>	Whole	75	167
	Leg/Thigh	75	167
	Breast	65	149
<b>Lamb</b>	Medium Rare	57	135
	Medium	63	145
	Medium Well	68	154
	Well Done	74	165
<b>Pork</b>		63	145
<b>Fish</b>		50	122
<b>Sweet</b>	Soft Ball	115	239
	Firm Ball	120	248
	Hard Ball	126	259
	Soft Crack	140	284
	Hard Crack	150	302
	Light Caramel	170	338
	Medium Caramel	180	356
	Dark Caramel	188	370

**2 YEAR GUARANTEE (UK & Ireland)** FKA Brands Ltd guarantees this product from defect in material and workmanship for a period of 2 years from the date of purchase, except as noted below. This FKA Brands Ltd product guarantee does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorised accessory; alteration to the product; or any other conditions whatsoever that are beyond the control of FKA Brands Ltd. This guarantee is effective only if the product is purchased and operated in the UK / EU. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and / or authorised, or repair of products damaged by these modifications is not covered under this guarantee. FKA Brands Ltd shall not be responsible for any type of incidental, consequential or special damages. To obtain guarantee service on your product, return the product post-paid to your local service centre along with your dated sales receipt (as proof of purchase). Upon receipt, FKA Brands Ltd will repair or replace, as appropriate, your product and return it to you, post-paid. Guarantee is solely through Salter Service Centre. Service of this product by anyone other than the Salter Service Centre voids the guarantee.

This guarantee does not affect your statutory rights. For your local Salter Service Centre, go to [www.salterhousewares.co.uk/servicecentres](http://www.salterhousewares.co.uk/servicecentres)

**2 YEAR LIMITED WARRANTY (Australia & New Zealand)**

**We** or us means HoMedics Australia Pty Ltd ACN 31 103 985 717 and our contact details are set out at the end of this warranty;

**You** means the purchaser or the original end-user of the Goods. You may be a domestic user or a professional user;

**Supplier** means the authorised distributor or retailer of the Goods that sold you the Goods in Australia and New Zealand; and

**Goods** means the product or equipment which was accompanied by this warranty and purchased in Australia and New Zealand.

**For Australia:**

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled, subject to the provisions of the Australian Consumer Law, to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled, subject to the provisions of the Australian Consumer Law, to have the Goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This is not a complete statement of your legal rights as a consumer.

**For New Zealand:**

Our Goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

**The Warranty**

HoMedics sells its products with the intent that they are free of defects in manufacture and workmanship under normal use and service. In the unlikely event that your HoMedics product proves to be faulty within 15 years from the date of purchase due to workmanship or materials only, we will replace it at our own expense, subject to the terms and conditions of this guarantee. The warranty period is limited to 3 months from the date of purchase for products used commercially/professionally.

**Terms and Conditions:**

In addition to the rights and remedies that you have under the Australian Consumer Law, Consumer Guarantees Act of New Zealand or any other applicable law and without excluding such rights and remedies warranty against defects:

1. The Goods are designed to withstand the rigors of normal household use and are manufactured to the highest standards using the highest quality components. Whilst unlikely, if, during the first 2 Years (3 months commercial use) from their date of purchase from the Supplier (Warranty Period), the Goods prove defective by reason of improper workmanship or materials and none of your statutory rights or remedies apply, we will replace the Goods, subject to the terms and conditions of this warranty.
2. We do not have to replace the Goods under this Additional Warranty if the Goods have been damaged due to misuse or abuse, accident, the attachment of any unauthorised accessory, alteration to the product, improper installation, unauthorised repairs or modifications, improper use of electrical/power supply, loss of power, malfunction

of damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, neglect, vandalism, environmental conditions or any other conditions whatsoever that are beyond the control of HoMedics.

3. This Warranty does not extend to the purchase of used, repaired or second-hand products or to products not imported or supplied by HoMedics Australia Pty Ltd, including but not limited to those sold on offshore internet auction sites.
4. This Warranty extends only to consumers and does not extend to Suppliers.
5. Even when we do not have to replace the Goods, we may decide to do so anyway. In some cases, we may decide to substitute the Goods with a similar alternative product of our choosing. All such decisions are at our absolute discretion.
6. All such replaced or substituted Goods continue to receive the benefit of this Additional Warranty for the time remaining on the original Warranty Period (or three months, whichever is the longest).
7. This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions, discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.
8. This Additional Warranty is limited to replacement or substitution only. As far as the law permits, we will not be liable for any loss or damage caused to property or persons arising from any cause whatsoever and shall have no liability or any incidental, consequential or special damages.
9. This warranty is only valid and enforceable in Australia and New Zealand.

**Making a Claim:**

In order to claim under this Warranty you must return the Goods to the Supplier (place of purchase) for replacement. If this is not possible, please contact our customer service department at the address below.

- All returned Goods must be accompanied by satisfactory proof of purchase which clearly indicates the name and address of the Supplier, the date and place of purchase and identifies product. It is best to provide an original, legible and unmodified receipt of sales invoice.
- You must bear any expense for return of the Goods or otherwise associated with making your claim under this Additional Warranty.
- This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions, discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.

**Contact:**

HoMedics Australia Pty Ltd, 14 Kingsley Close, Rowville, VIC 3178  
(03) 8756 6500

Phoenix Distribution NZ Ltd, Unit 1/9 Orbit Drive, Albany, Auckland, New Zealand  
0632 (09) 475 0007



**Manufacturer & UK Importer:**

FKA Brands Ltd, Somerhill Business Park, Tonbridge, Kent TN11 0GP, UK

**EU Importer:**

FKA Brands Ltd, 29 Earlsfort Terrace, Dublin 2, Ireland

Customer Support: +44(0) 1732 360783 | [support@salterhousewares.co.uk](mailto:support@salterhousewares.co.uk)

IB-515-0719-01