


SALTER

SALTER COOK BLUETOOTH RECIPE THERMOMETER

Instructions and Guarantee



Register your product today at
www.salterhousewares.co.uk/product-registration



Transform your culinary experience with **SALTER COOK**.

Download the free **SALTER COOK** App and create your own personal cookbook, capturing recipes from your favourite websites at the click of a button as well as adding your own recipes by hand.

Access your recipes anytime from your tablet and/or phone, whether you are at home or at the supermarket.

Connect the app to your **SALTER COOK** thermometer for fully interactive temperature measurement.

See the temperatures from your recipes automatically linking to the thermometer display on the app.

Check progress of your cooking at any time on your phone or tablet. Use the extensive in-app library of preset temperatures for meat, confectionery, jam etc or set your own preferred temperatures.



Measure both oven temperature and food temperature and enjoy perfect results every time, whatever you cook.

Complete the experience with the **SALTER COOK** scale (sold separately) for interactive weighing and measuring, making recipes quicker and easier to follow than ever before.

INSTRUCTIONS FOR USE

BEFORE FIRST USE: Sterilise the food probe – see 'CLEANING'.

INSERT BATTERY (1 x CR2032): Ensure the + terminal faces up.

TO CONNECT: Your SALTER COOK thermometer is supplied with two probes – an oven probe for measuring oven temperature and a food probe for measuring food temperature. Plug either or both of these probes into the thermometer unit and press the  button on the side of the thermometer unit, the Bluetooth icon will light. Make sure your phone or tablet has Bluetooth turned on, open the SALTER COOK app (available free from App Store and Google Play) and select , the app and thermometer will automatically connect. The Bluetooth icon will flash to confirm the connection.

NOTE: Your thermometer can only be connected to one device at a time and will automatically connect to the nearest device. Pressing the Bluetooth refresh icon will cause the scale to disconnect and reconnect to the nearest device.

SETTING TARGET TEMPERATURES: If you are following a recipe on your SALTER COOK app, simply select (with a long press) any underlined temperature in the recipe, or to set manually just touch the target icon on the thermometer view. When setting manually you will also be given the option to use a preset temperature from the in-app library.

NOTE: To preserve battery your thermometer will automatically turn off after 3 hours. If you anticipate that your cooking time will be longer than 3 hours we suggest that you put your probe & thermometer in position at the start of cooking but don't turn

on the thermometer and set your target until part way through cooking.


ALERTS: At any time during cooking you can check the current temperature(s) by opening the thermometer view on the app. When the target temperature is reached an alarm will sound on the app and also on the thermometer unit.

USING THE OVEN PROBE: Slip the oven probe into the oven clip and hang it from a shelf near to the centre of the oven. Keep the cord end of the probe clear of oven walls / heating elements. Carefully close the oven door onto the cord and position the thermometer unit outside of the oven with the cord out of reach of children.

USING THE FOOD PROBE:

For meat, fish and poultry, insert the probe into the centre (thickest part) avoiding bone, fat and gristle. For whole poultry, insert into the thickest part of the thigh. Food can be placed in the oven with the probe in place throughout cooking. Carefully close the oven door onto the cord and position the thermometer unit outside of the oven with the cord out of reach of children. For sauces, jam, caramels etc, the food probe can be inserted into the pan clip and then clipped to the side of the saucepan. The tip of the probe should be in the liquid but not touching the pan. For deep frying (checking oil temp), the pan clip can be used as above, but we recommend removing the thermometer once the oil temperature has stabilised and before adding food.

SWITCH OFF: To switch off manually, clear the target temperatures on the app and press  button on the side of





thermometer unit for 2-3 seconds. Auto-switch off will occur if the unit is not connected to the app and no target has been set after 1 minute. If a target has been set, auto-off will occur after 3 hours. Always switching off manually after use will help preserve battery power.

CLEANING: It is recommended that food probe is sterilised before each use by placing the end of the probe in boiling water for 2 mins. After use, clean the food probe thoroughly with a damp soapy cloth then dry. The oven probe, cords, clips and thermometer unit should be wiped clean only. Do not immerse or use chemical cleaners.

IMPORTANT:

- Remove flat batteries immediately
- Always wear heat resistant gloves to handle the probes/cords/ clips **WARNING HOT SURFACE!**
- Do not immerse the thermometer unit in liquid or allow it to become wet.
- The thermometer is NOT suitable for use in a microwave oven
- DO NOT place the thermometer unit inside the oven or grill, or on direct heat
- The probe and cord must not be used in temperatures exceeding 250°C/482°F
- Never use the probe to lift or turn food items
- This appliance can be used by children aged from 14 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

 **WEEE EXPLANATION** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

 **BATTERY DIRECTIVE** This symbol indicates that batteries must not be disposed of in the domestic waste as they contain substances which can be damaging to the environment and health. Please dispose of batteries in designated collection points. **Caution:** Risk of explosion if battery is replaced by an incorrect type.

2 YEAR GUARANTEE (UK & Ireland) FKA Brands Ltd guarantees this product from defect in material and workmanship for a period of 2 years from the date of purchase, except as noted below. This FKA Brands Ltd product guarantee does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorised accessory; alteration to the product; or any

other conditions whatsoever that are beyond the control of FKA Brands Ltd. This guarantee is effective only if the product is purchased and operated in the UK / EU. A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and / or authorised, or repair of products damaged by these modifications is not covered under this guarantee. FKA Brands Ltd shall not be responsible for any type of incidental, consequential or special damages. To obtain guarantee service on your product, return the product post-paid to your local service centre along with your dated sales receipt (as proof of purchase). Upon receipt, FKA Brands Ltd will repair or replace, as appropriate, your product and return it to you, post-paid. Guarantee is solely through Salter Service Centre. Service of this product by anyone other than the Salter Service Centre voids the guarantee.

This guarantee does not affect your statutory rights. For your local Salter Service Centre, go to www.salterhousewares.co.uk/servicecentres

2 YEAR LIMITED WARRANTY (Australia & New Zealand)

We or us means HoMedics Australia Pty Ltd ACN 31 103 985 717 and our contact details are set out at the end of this warranty; **You** means the purchaser or the original end-user of the Goods. You may be a domestic user or a professional user; Supplier means the authorised distributor or retailer of the Goods that sold you the Goods in Australia and New Zealand; and Goods means the product or equipment which was accompanied by this warranty and purchased in Australia and New Zealand.

For Australia:

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled, subject to the provisions of the Australian Consumer Law, to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled, subject to the provisions of the Australian Consumer Law, to have the Goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This is not a complete statement of your legal rights as a consumer.

For New Zealand:

Our Goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This guarantee applies in addition to the conditions and guarantees implied by that legislation.

The Warranty

HoMedics sells its products with the intent that they are free of defects in manufacture and workmanship under normal use and service. In the unlikely event that your HoMedics product proves to be faulty within 15 years from the date of purchase due to workmanship or materials only, we will replace it at our own expense, subject to the terms and conditions of this guarantee. The warranty period is limited to 3 months from the date of purchase for products used commercially/professionally.

Terms and Conditions:

In addition to the rights and remedies that you have under the Australian Consumer Law, Consumer Guarantees Act of New Zealand or any other applicable law and without excluding such rights and remedies warranty against defects:

1. The Goods are designed to withstand the rigors of normal household use and are manufactured to the highest standards using the highest quality components. Whilst unlikely, if, during the first 2 Years (3 months commercial use) from their date of purchase from the Supplier (Warranty Period), the Goods prove defective by reason of improper workmanship or materials and none of your statutory rights or remedies apply, we will replace the Goods, subject to the terms and conditions of this warranty.
2. We do not have to replace the Goods under this Additional Warranty if the Goods have been damaged due to misuse or abuse, accident, the attachment of any unauthorized accessory, alteration to the product, improper installation, unauthorised repairs or modifications, improper use of electrical/power supply, loss of power, malfunction of damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, neglect, vandalism, environmental conditions or any other conditions whatsoever that are beyond the control of HoMedics.
3. This Warranty does not extend to the purchase of used, repaired or second-hand products or to products not imported or supplied by HoMedics Australia Pty Ltd, including but not limited to those sold on offshore internet auction sites.
4. This Warranty extends only to consumers and does not extend to Suppliers.
5. Even when we do not have to replace the Goods, we may decide to do so anyway. In some cases, we may decide to substitute the Goods with a similar alternative product of our choosing. All such decisions are at our absolute discretion.
6. All such replaced or substituted Goods continue to receive the benefit of this Additional Warranty for the time remaining on the original Warranty Period (or three months, whichever is the longest).
7. This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions, discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.

8. This Additional Warranty is limited to replacement or substitution only. As far as the law permits, we will not be liable for any loss or damage caused to property or persons arising from any cause whatsoever and shall have no liability or any incidental, consequential or special damages.
9. This warranty is only valid and enforceable in Australia and New Zealand.

Making a Claim:

In order to claim under this Warranty you must return the Goods to the Supplier (place of purchase) for replacement. If this is not possible, please contact our customer service department at the address below.

- All returned Goods must be accompanied by satisfactory proof of purchase which clearly indicates the name and address of the Supplier, the date and place of purchase and identifies product. It is best to provide an original, legible and unmodified receipt of sales invoice.
- You must bear any expense for return of the Goods or otherwise associated with making your claim under this Additional Warranty.
- This Additional Warranty does not cover items damaged by normal wear and tear including but not limited to chips, scratches, abrasions, discolouration and other minor defects, where the damage has negligible effect on the operation or performance of the Goods.

Contact:

HoMedics Australia Pty Ltd, 14 Kingsley Close, Rowville, VIC 3178
(03) 8756 6500

DECLARATION OF CONFORMITY

Hereby, HoMedics Group Ltd, declares that this radio equipment is in compliance with the Essential requirements and other relevant provisions of Radio Equipment Directive 2014/54/EU. A full version of the Declaration of Conformity can be obtained from www.salterhousewares.co.uk/DoC
Operating frequency band – 2402-2480MHz
Maximum radio-frequency power transmitted -0.23dBm

ELECTROMAGNETIC COMPATIBILITY

This product is intended for domestic use.

ADVICE TO THE USER This is a sensitive electronic device and as such may be temporarily affected by Radio Transmitting Devices being used in close proximity to it (such as Mobile Phones etc.) or high levels of Electrostatic Interference. If this happens please remove and re-install the battery to re-establish normal working. If the problem persists then contact your local agent.

FKA Brands Limited, Somerhill Business Park,

Five Oak Green Road, Tonbridge, Kent TN11 0GP, UK
Customer Support: +44(0) 1732 360783 | support@salterhousewares.co.uk
HoMedics Australia Pty Ltd, 14 Kingsley Close, Rowville, VIC 3178, Australia
Customer Support: 03-8756-6500 | cservice@homedics.com.au



IB-593-1219-05